

TROUBLE SHOOTING

Direct Cool Refrigerator		
Sr. No	Symptoms	Checks
1	The appliance is not operating at all or the temperature is too high	<p>Check that the power plug is correctly connected.</p> <p>Is the temperature control on the control box correctly set?</p> <p>Does sun shine on the appliance or are there any heat sources nearby?</p> <p>Is the back of the appliance too near to the wall?</p>
2	Condensation forms on the inside of the appliance and around vegetables	<p>Food with higher water content is stored uncovered or the door has been left open for a long time.</p> <p>Store the food with cover or in sealed containers.</p>
3	The food in the refrigerator is frozen	<p>Is the temperature control on the control box set to the coldest temperature?</p> <p>Is the surrounding temperature too low?</p> <p>Did you put the food with higher water content in the refrigerator?</p>
4	There are unusual noises	<p>Check that the appliance is installed on a stable, level floor.</p> <p>Is the back of the appliance too near to the wall?</p> <p>Have any foreign objects fallen behind or under the appliance?</p> <p>A ticking sound maybe heard inside the appliance; this is normal.</p>